



Download the Zebra, print it out onto thin card. Cut out and assemble the pieces following the fully illustrated, clear instructions and you will soon have your very own animated paper Zebra.


Rock the model back and forth and he stretches out his neck in a charming way.

Make two and they will kiss!


XXX



### Assembly Instructions




----- Mountain fold  
● Make a mountain fold.



- - - - - Valley fold  
● Make a valley fold.



— Scissors line  
● Cut along the line.



— Cut in line  
● Make a cut.



A1 Glue spot  
● Glue parts with the same number together.

### Tools and Materials



Scissors, set square, glue (such as woodwork glue), metal rod, spatula, a used pen, toothpicks, tweezers (useful for handling small parts).

### Assembly Tip




Before gluing, crease the paper along mountain fold and valley fold lines and make sure rounded sections are nice and stiff.

### Caution



This craft requires the use of glue, scissors, tweezers, and other tools which may be dangerous to young children. Please keep them out of reach of children while you work.

### Handy Hints



Trace along the folds with a used pen (no-ink) to get a sharp, easier fold.

● Before assembling: Use spray adhesive to attach page 04 to the back of this paper. \*Be careful not to put it upside down.  
We recommend using thick matte photo paper for the front sides.



● Before assembling: Use spray adhesive to attach page 05 to the back of this paper. \*Be careful not to put it upside down. We recommend using thick matte photo paper for the front sides.

